


17. CHASSIS EXPLODED VIEW (CONTROL SECTION)



Parts List

NOTE:
• For your parts Stock Control, the fast moving items are indicated with the marks ** and *.
** : GENERALLY MOVES FASTER THAN *.
This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.
• Parts whose parts numbers are omitted are subject to being not supplied.
• Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

Mark	No.	Part No.	Description	Mark	No.	Part No.	Description
	1.	CDE1168	DIN Cord	54.			Plug
	2.	PMS26P040FMC	Screw	55.		BMZ26P050FMC	Screw
	3.		Bracket	56.			Case
	4.		Connector	● 57.		CWR1002	Power Supply Assy
	5.		Plug	58.		CNV1157	Holder
	6.	CKS1124	Connector	59.		BPZ20P100FMC	Screw
	7.	PMS26P040FMC	Screw	60.		BPZ20P080FMC	Screw
	8.		Insulator	61.			Insulator
	9.		Shield	★ 62.		LN81RC5V	LED
●	10.	CWX1026	Pre Amp Assy	★ 63.		LN31GC6V	LED
	11.	PMS26P040FMC	Screw	64.		CAW1012	FL Tube
	12.	BPZ20P050FMC	Screw	● 65.		CWX1023	Display Unit
	13.	CNV1216	Lens	● 66.		CXK2010	CD Mechanism Unit
	14.	CNM1265	Cushion	67.			Holder
★	15.	CAC1148	Button	68.			Plug
	16.	CXA1373	Grille Unit	69.			Plug
	17.	PMS30P050FMC	Screw	70.			Plug
	18.	CNV1202	Holder	71.			Plug
	19.	CNM1249	Cushion	★★ 72.		HSH-156	Switch (Main/Sub)
	20.	CNM1250	Cushion	73.		CKS1070	Connector
★	21.	CAC1162	Button (SEEK TRACK +)	74.		CKS-719	Connector
★	22.	CAC1163	Button (SEEK TRACK -)	75.			Bracket
★	23.	CAC1150	Button (BAND/REL)	76.		WH26FMC	Washer
	24.	CNV1158	Lens	77.		CPV1005	Buzzer
	25.	CNM1177	Cushion	78.		CKS-721	Connector
★	26.	CAC1153	Button (0)	79.		CKS-720	Connector
★	27.	CAC1154	Button (1)	80.		CKS1122	Connector
★	28.	CAC1155	Button (2)	81.			Plug
★	29.	CAC1156	Button (3)	● 82.		CWX1021	Main Assy
★	30.	CAC1157	Button (4)	83.		CNV1159	Holder
★	31.	CAC1158	Button (5)	84.		CDE1171	Cord
★	32.	CAC1161	Button	85.		BMZ30P040FMC	Screw
	33.	CNS1119	Escutcheon	86.		CNB1108	Case
★	34.	CAC1160	Button (VOL/BAL L)	87.		CNM1166	Cushion
★	35.	CAC1159	Button (VOL/BAL R)	88.			Insulator
	36.	CNM1266	Cushion	89.			Insulator
	37.		Holder	90.			Chassis
★	38.	CAC1149	Button (EJECT/RELOAD)	91.		CBA1019	Screw
★	39.	CAC1152	Button (FUNCTION)	92.		BMZ26P060FMC	Screw
★	40.	CAC1151	Button (LOUD)	★ 93.		CAC1164	Knob
	41.	CDE1169	Cord	94.		CSG-255	Switch (Clock)
	42.	CDE1170	Connector	★★ 95.		CCS1030	Volume
	43.	VACANT		96.			Anti Logic Unit
	44.	PMA40P060FMC	Screw	97.			Bracket
	45.	CDE1172	Cord	98.		CBL1019	Spring
	46.		Case	99.		BMZ30P030FZK	Screw
★★	47.	CSG-255	Switch	100.		CBA1049	Screw
★	48.	BG4524K	LED	101.		CKS1025	Connector
★	49.	BG5724K	LED	★ 102.		CAC1148	Button
	50.	CNV1218	Cover				
	51.	CNV1259	Cover				
	52.	CNV1215	Lens				
	53.	CNM1179	Cushion				

Fig. 92